

CIRCUITWERKES
Makers of Innovative Electronics

**Operation &
Technical Manual**

**SiteSentry4 &
SiteSentry4-LE
Web Based Remote Site Monitor &
Controller**

Firmware Version 1.0 / Software v1.0
Revised 10/04/2012

Hardware Version 1
Manual Rev 0.8

Table of Contents

Contacting CircuitWerkes.....	4
Unpacking your SiteSentry4.....	4
Safety Information.....	4
Product Overview.....	5
Introduction.....	5
Standard SiteSentry4 Inputs and Outputs.....	5
SS4-LE Inputs and Outputs.....	7
Connecting your SiteSentry4 to other equipment6.....	8
Metering Inputs	8
Relay Outputs:.....	8
External Status Inputs.....	8
Using the Internal Web Server.....	9
Connecting to the SiteSentry4 for the first time:.....	10
Using the SiteSentry4's Web server:.....	11
Logging In:.....	11
Monitoring and control using the Web server:.....	12
Calibrating Meters:	14
Setting Alarm Points:	16
Event Triggers:.....	17
Sequences:.....	18
Logging:.....	19
E-mail notifications Setup.....	21
Connectivity (Network settings):.....	22
Passwords and system utilities:.....	23
Optional Streaming.....	24
Receive Audio hardware:.....	25
Software:.....	26
Specifications.....	27
SiteSentry4 Schematic.	28
Warranty.....	29

NOTE: This technical manual & information presented within is subject to change.

Contacting CircuitWerkes

For help with setting up or operating the SiteSentry4, please contact us at the following:

Phone: 352-335-6555

E-mail: info@circuitwerkes.com

Website: www.circuitwerkes.com

Unpacking your SiteSentry4

Note: CircuitWerkes is not responsible for product damage during shipment. Inspect your shipment carefully for external signs of damage. CircuitWerkes suggests that you unpack your shipment as soon as possible after receipt to inspect it for signs of damage that might not be visible from the outside. If the shipment appears to be damaged, keep the original boxes and packing material for inspection by the carrier. All damage claims should be made directly to the carrier. Do not delay. Call the carrier as soon as damage is discovered.

You should have received the following items with each SiteSentry4 that you have purchased:

- [] (1) CircuitWerkes 15V Power Supply
- [] (1) Standard Network cable (yellow)
- [] (1) Printed copy of the manual

If you have not received all of the items shown with your shipment, please carefully check inside the box or boxes because items occasionally get lost in the packing materials and can be hard to find. If your items are not found, please call CircuitWerkes at 352-335-6555 or e-mail us at support@circuitwerkes.com.

In case your product is in need of service our shipping information is as follows:

CircuitWerkes, Inc.

Attn: RMA #

2805 NW 6th Street

Gainesville, Florida, 32609, USA

Please obtain an RMA from us and verify the address before returning any products



Safety Information

WARNING!

The SiteSentry4's relays are not intended to switch hazardous voltages. The exposed terminals make connecting such voltages to the SiteSentry4 extremely dangerous and it should never be attempted. The terminal strips are not designed to shield humans from potentially dangerous Voltages. Contact with high Voltages can cause serious injury or death. The maximum recommended Voltage for the SiteSentry4 is 30V. Switching of high voltages should only be done externally and in a manner that isolates the voltages from accidental contact with people.

Surge Protection

Although the SiteSentry4 has built-in resistance to voltage changes, we recommend that you use a power surge protector or line conditioner on the incoming AC line. Lightning strikes and other high surges in voltage levels will damage your SiteSentry4 and connected equipment if it is not properly protected.

UPS Standby Power System

We recommend that you connect your SiteSentry4 to a battery backup system. While all operating and user parameters are stored in non-volatile RAM, brownout conditions and lightning induced spikes can disable or damage equipment. A UPS helps minimize the risk to the SiteSentry4 and has the added benefit that it will then be able to notify you of the power outage by SMS or e-mail, depending on the configuration of your system.

Product Overview

Introduction

The CircuitWerkes SiteSentry4 is a Web enabled Remote site controller and monitoring tool. An internal Web server lets you visually monitor your site from any Web browser, anywhere in the world. When an alarmable condition is detected, the SiteSentry4 can perform user-programmed, automated, sequences of actions and can also respond to user control via the network or via external contact closure inputs. Three levels of user control are available ranging from reader up to administrator.

The SiteSentry4 is available in two versions. The standard SS4 is equipped with active, balanced, audio inputs and a calibration control for each audio input. There is also an audio streaming input control for each channel, available when the optional streaming module is used.. Additionally, when used with the streaming module, the standard SS4 supports a stereo balanced audio output module for use with receive audio streams.

The SS4-LE version offers the same DC metering and relay controls but the audio metering input is unbuffered and unbalanced. The streaming option is also not supported on the LE version. Both versions of the SS4 audio metering can detect silence or overload.

In addition to the four DC metering inputs, an onboard temperature sensor allows you to monitor the local temperature.


Up to two SiteSentry4s can be optionally rack mounted in a single sized rack shelf. Administrators can perform all setup through the Web server.

Key Features

- *Internal Web Server lets you see your status from anywhere in the world*
- *Web server meters are fast responding*
- *Four balanced DC metering inputs*
- *Stereo audio monitor input*
- *Onboard temperature sensor*
- *6 User-programmed relays (2 DPDT) close automatically or via Web control*
- *81 User-definable alarm conditions can trigger up to 3 actions per alarm*
- *External trigger inputs can activate user-defined actions*
- *Relays can be momentary or latching.*
- *DHCP or Static IP capable*
- *Onboard e-mailing & texting of alarms*
- *Field upgradeable firmware keeps you up to date..*
- *Optional send or receive audio streaming upgrade available soon.*

Standard SiteSentry4 Inputs and Outputs

As seen in Figure 1 below, the SiteSentry4 has a number of connectors on the back panel to interface with your equipment. The following table is a list giving the name of each connector, followed by a brief description of its function.



Standard SiteSentry4 Back panel connections

Name	Type	Description
Relay Outputs	Screw Terminals	The SiteSentry4 has six relays. These relays are not associated with any particular metering channel. They are completely independent and any event on either channel can be used to operate any relay. Everything is completely user defined.
Ext 1 & 2	Screw Terms	External Status inputs. Can trigger actions/alarms.
Network	RJ-45	Connects your LAN or Internet to the internal Web server.
Status LEDs	G & Y LEDs	Blinking yel = proper operation. Solid green = Net connected.
Input 1	3-terminal	Site input to feed channel 1 analog input for site monitoring.
Input 2	3-terminal	Site input to feed channel 2 analog input for site monitoring.
Input 3	3-terminal	Site input to feed channel 3 analog input for site monitoring.
Input 4	3-terminal	Site input to feed channel 4 analog input for site monitoring.
Ch1 thru 4 Cal	Trimmer	Adjusts the input level to the # A/D converters (range set)
Stat Src	Jumper	Select internal or external voltage source for status inputs
Com Funct	Jumper 1x3	Select com=ground or com=floating for status inputs
Audio In	3-terminal	Unbal. Stereo audio input for remote (visual) audio monitoring.
CH1 & CH2 Cal	Audio Trimmer	Adjusts the input level to the audio A/D converters (range set)
Power In	2.1mm Barrel	Accepts 14-18 V AC or DC @ 200mA


Important Note: the DPDT relays are rated at 1Amp while the SPST relays are rated at 10va or 100mA (non inductive).

SiteSentry4 Front panel indicators:

Name	Type	Description
PWR	LED Indicator	Indicates that the main power supply is operating.
Link	LED Indicator	Lights up whenever the network is connected
Cust 1	LED Indicator	Lights when a user defined event triggers this LED
Cust 2	LED Indicator	Lights when a user defined event triggers this LED

SS4-LE Inputs and Outputs

As seen in Figure 2 below, the SiteSentry4 has a number of connectors on the back panel to interface with your equipment. The following table is a list giving the name of each connector, followed by a brief description of its function.



SS4-LE Back panel connections

Name	Type	Description
Relay Outputs	Screw Terminals	The SiteSentry4 has six relays. These relays are not associated with any particular metering channel. They are completely independent and any event on either channel can be used to operate any relay. Everything is completely user defined.
Ext 1 & 2	Screw Terms	External Status inputs. Can trigger actions/alarms.
Network	RJ-45	Connects your LAN or Internet to the internal Web server.
Status LEDs	G & Y LEDs	Blinking yel = proper operation. Solid green = Net connected.
Input 1	3-terminal	Site input to feed channel 1 analog input for site monitoring.
Input 2	3-terminal	Site input to feed channel 2 analog input for site monitoring.
Input 3	3-terminal	Site input to feed channel 3 analog input for site monitoring.
Input 4	3-terminal	Site input to feed channel 4 analog input for site monitoring.
Ch1 thru 4 Cal	Trimmer	Adjusts the input level to the # A/D converters (range set)
Stat Src	Jumper	Select internal or external voltage source for status inputs
Com Funct	Jumper 1x3	Select com=ground or com =floating for status inputs
Audio In	3.5mm Stereo	Unbal. Stereo audio input for remote (visual) audio monitoring.
Power In	2.1mm Barrel	Accepts 14-18 V AC or DC @ 200mA

SiteSentry4 Front panel indicators:


Name	Type	Description
PWR	LED Indicator	Indicates that the main power supply is operating.
Link	LED Indicator	Lights up whenever the network is connected
Cust 1	LED Indicator	Lights when a user defined event triggers this LED
Cust 2	LED Indicator	Lights when a user defined event triggers this LED

Important Note: the DPDT relays are rated at 1Amp while the SPST relays are rated at 10va or 100mA (non inductive).

Connecting your SiteSentry4 to other equipment

Metering Inputs

The SiteSentry4 has four, differential, DC site inputs that it monitors. The inputs are ground referenced. These are on depluggable (“Phoenix” style) connectors. Gain control potentiometers are associated with each DC input to let you calibrate your site level to the internal metering of the SiteSentry4. Normally, you will apply the highest expected metering sample to the input and then set the meters for 2/3 to 3/4 of full scale using a scale factor of 1.0 (default). This sets the nominal range of the A/D converter. You can then scale the sample in firmware to read whatever you want. In addition to the DC metering inputs, the standard SiteSentry4 has balanced audio inputs & the SiteSentry4 LE has a 3.5mm, unbalanced, stereo audio input for metering of local audio. **The typical metering configuration is to hook positive sample voltages between (+) and Ground.**




Relay Outputs:

The SiteSentry4 is equipped with 6 relays to provide you with control over your external equipment or to switch audio.


Relays K1 and k2 are DPDT relays which are ideal for use as a simple, stereo, audio switcher. All relays can also be operated in momentary mode, so they can be used as standard control outputs, as well. All six contacts of each DPDT relay are brought out on the back panel barrier strip, so any and all of their contacts may be utilized. The DPDT relays are labeled Common (ComA or ComB), Normally Open (NOA or NOB) and Normally Closed (NCA or NCB). A and B refer to which set of contacts are being used. The COM contact is connected to NC when the relay is off and the COM contact is connected to NO when the relay is energized. Electrically, it is possible to make contact closures between all of the A or all of the B but A and B sides are isolated from each other. Each of the remaining four relays are normally open SPST (form A) contacts that can be used for general control purposes. The SPST relays are rated at 10va, non-inductive. Higher loads may damage them. The DPDT relays are rated for 1A max., non-inductive. None of the relays have voltages sourced to the contacts internally. All closures are dry (no voltage is supplied on any of the contacts).

External Status Inputs

The SiteSentry4's status inputs can be used to determine the status (on/off) of your equipment. The status input connectors are located immediately to the left of the network connector and are labeled Stat1 and Stat2 and common. The optocouplers are bi-directional meaning that current can flow in either direction. This means that these inputs can be triggered by supplying a voltage to them or by supplying an internal voltage and pulling them to ground. The operation of these inputs is determined by the settings of JP3 and JP4. By default, the status inputs are pulled up internally. The com terminal is jumpered to ground. These inputs accept contact closures to ground as inputs, or you can supply AC or DC voltage to them by changing jumper configurations. Max input voltage is 15V and jumper JP4 must be “off” before an external voltage is supplied. Status inputs can be used to trigger actions when closed or opened. When applying your own voltage, the polarity is not important. The optocouplers will conduct in either direction. When using the Status inputs with the internal power supply, you will need to connect your device's ground to the SiteSentry4's actual ground (JP3 in B).



HINT: In default setup, turn on status inputs by connecting the trigger input to comm



Note: The status “common” is a ground when JP3 is set to the “B” position (default). If JP3 is set to “A”, then comm is floating and can be used to source a voltage to the optoisolators. If sourcing a voltage, JP4 (the internal pull-up) should also be removed.

Using the Internal Web Server

Networking basics:

Before reading any further, we would like to mention that the following section is not intended to be a comprehensive guide to networks, nor does it necessarily describe your network. Indeed, we have found that networks vary quite a lot and yours will probably be different than is described here. We assume that you, or a network administrator, is familiar with your network and knows how to set it up to accommodate Web servers that exist within your network. The brief discussion provided below is only intended to be used as a very non-specific description of how a network might function.

In Internet land, devices on your network get unique IP addresses because each piece of hardware has a serial number embedded into it. Every device with a serial number, called a MAC address, has to get an IP address assigned to it in order to function using the networking protocol called TCP/IP, which is what is used for the Internet. The router in your network uses those IP addresses that it assigns to keep track of what data requests have been made and how to route responses to the devices that need data. In a way, the IP address is sort of like a nickname that computers use to talk to each other. A computer will only respond if it has been called by name. So, the IP addresses are what one computer uses to address or talk to another computer. The router also uses those IP addresses to manage the flow of communications between each computer so that they are not all talking at once like an old fashioned party-line.

IP addresses are usually doled out within a fixed range, so it's also easier for humans to remember a device's location via its IP address than to try to remember every item's MAC number. For instance an internal network might use the IP range of 192.168.1.### where ### can be 001 through 254. Once the network administrator has set up the address range, he or she only has to keep track of what's assigned to the last three digits of the address range.

Generally, simple networks are divided into two sets of addresses. There are the addresses that exist inside the network (called the private or LAN side) and then there are addresses that exist on the Internet (public or WAN) side of the network. We've already described the private side above, but getting stuff on the private side to talk to the public side can be tricky.

When you have one device that is connecting your internal network to the Internet, like a cable modem or DSL modem, it also has a unique serial number, so it gets assigned an IP address from your ISP. But the ISP only sees the modem, not other equipment on the inside of your network, so they cannot assign multiple IP addresses (actually they can, but that's another story). Although you probably only have one IP address, you will have a whole range of port numbers that you can use for each IP address that exists on the private side of your network. Usually, different types of communications use standardized ports to talk to devices. For instance http (Web browsing) is mostly done on port 80. FTP is usually port 21. E-mail might use port 25. Often, we want to set our network connection up to pass port 80 to some device on our network, like the SiteSentry4, that serves up web pages. We do that by telling the router/firewall to pass port 80 requests to the IP address that we know we have previously assigned to the SiteSentry4. To do that, we have to tell our firewall that it's okay to send port 80 requests to the SiteSentry4, otherwise it'll just block those requests if they come from the public side of the firewall. As described earlier, each device on the private side needs a static IP address that is set by the network administrator. So, each item on the inside of a network that will be communicating with the outside world has to have an IP address within the local network **AND** it must also have the appropriate port opened on the firewall. On the Internet side of the firewall, there is usually only the main IP address and the port number.

When you put it all together it might look like this:

Public IP address 67.234.98.135, port 630 could be mapped to internal IP address 192.168.1.250, port 80. So a browser request made to 67.234.98.135:630 would serve up a web page because you would really be talking to 192.168.1.250:80. Once you have that properly configured, your SiteSentry4 can serve up Web pages from inside of your network to the Internet.

Connecting to the SiteSentry4 for the first time:

Most networks use a router as their central hardware. When a device is plugged into a router, the device normally obtains an IP address from the router using a process called DHCP. By default, the SiteSentry4 obtains a DHCP address from your network's DHCP server. In order to connect to the SiteSentry4, you can use one of two methods: First, the device has a default netbios name of "sitesentry4". You can type <http://sitesentry4/> (no www) and your browser should take you to the login screen. On some browsers, you must enter the entire <http://sitesentry4/> including the starting "http" and the backslash after the 4. Some browsers will work either way. Note that netbios names are not supported in some operating systems such as Android. The second method requires you to know what its network IP address is. An IP address inside a network will usually look like XXX.XXX.X.XXX, for example 192.168.1.100. Your router knows this information and you can usually find out what the address is by logging into the setup page of your router. Most routers have a page that shows the attached devices. This can be shown as part of the router's DHCP page, or it may be shown in a separate LAN discovery page. Once you know the IP address of your device, you will be able to connect to it by entering the address into your browser's address bar. You can use the CircuitWerkes Netscanner utility, found on our Website or on the CD that came with your SiteSentry4 to locate the device on your network. Netscanner will identify the SiteSentry4 by name and will show you the IP addresses of all objects on your network that respond to pings.

If you do not use a router in your network or if you want to configure your SiteSentry4 via a direct connection, the default IP address for this device is 192.168.1.250. If making a direct connection, you must set your computer's network settings to match the SiteSentry4's settings. Your PC's TCP/IP properties must be set to 192.168.1.xxx with a netmask of 255.255.255.0. Once you have connected to the SiteSentry4, you can set its IP address to whatever you wish from the configuration page.

The Web server uses port 80, but this can be changed after login. Often, sites have multiple devices that want to use port 80, including some routers. You have two choices: first, you can change ports on the SiteSentry4's Webserver. Second, your router can simply redirect a different outside (WAN) port to the individual Web servers' inside IP addresses. For instance, the SiteSentry4 and an site IP device each have Web servers using port 80. The SiteSentry4 has an internal IP address of 192.168.1.250 and suppose that the site device has an IP of 192.168.1.200. If you are on the inside (LAN) of the network everything looks great. You can browse to either device and everything works. To access the site from the outside, you must open a "pinhole" that allow data to pass from browsers to your SiteSentry4. You can encounter a problem if you try to route WAN port 80 to LAN port 80 for both Web servers. Only one will be assigned. You will not gain access to the second one. Instead, redirect LAN port 80 for each device to a different outside port, such as 800 and 801. In practice, you would access your site by entering its IP address followed by a colon and the port number (xxx.xxx.xxx.xxx:800), or by its URL name followed by the port (www.mysite.com:800).

Differentiating multiple devices on a common network:

The SiteSentry4 MAC address is not changeable, IP address and Netbios name of the device. These can be important when multiple CircuitWerkes Webserver based products are used at a common location. In that case, you will want to assign a unique MAC address to each box so that your network can distinguish between them. Likewise, you should change the Netbios name so that each device can be found by a unique name.

Using the SiteSentry4's Web server:

Your SiteSentry4 contains an onboard Web server which is the heart of its monitoring capability. This Web server has proved to be very stable & supports multiple browsers. Although the interface looks simple, the real power of the Web server lies “under the hood”, in its speed. Readings are continually updated, at a user defined speed, which is much faster than many competing products. Your actual speed depends upon the network and upon your PC's horsepower. Your PC reads the raw data from the SiteSentry4 and “draws” the meter movements. Your computer's ability to draw quickly has a direct effect upon how frequently the meters move. The default update speed is 500ms which updates the meter position 2x each second. Speeds of 50ms can be achieved on fast networks, however, if you request data too fast, your network or your PC may not be able to handle it and you can get a periodic message saying that the SiteSentry4 is not responding. If that happens frequently, slow the updating down by using a bigger number in the “Update Interval” box.


Logging In:



By browsing to whatever IP address your SiteSentry4 has, you will be presented with a login screen. **The default administrator's login is 12345678**, unless you have previously set this differently from the configuration menu. There are three access levels to the SiteSentry4, reader, controller and administrator. Only administrators can configure the SiteSentry4. Controllers can operate relays while reader level has no control. The default administrator's password is simply 12345678. Passwords are a maximum of 8 characters.

If you are using Internet Explorer and you incorrectly enter the password one time, you may have to close your browser and reload it because IE cache's the passwords and will try to use them even if they don't work and you have tried to enter a different password. To avoid that problem change your IE settings for temporary files so that Explorer checks for new versions of stored pages on every visit. Other browsers such as Firefox, Opera and Chrome do not, generally, have this problem, however, we still recommend IE be used for changing configuration of the SiteSentry4. Any browser can be used for monitoring.

Once you have entered the correct password, it will take a few seconds to load the SiteSentry4's page. Once done, you will have access to the metering and controls of the SiteSentry4. If you are an administrator, you will also be able to manage the SiteSentry4's settings. If the page does not properly load the first time, use the F5 key to refresh the page.



Monitoring and control using the Web server:

The screenshot displays the 'My Transmitter' web interface. It features a central dashboard with several analog-style meters: Final Volts (78.73 Volts), Final Amps (36.57 Amps), Output Power (3963.24 Watts), Reflected PWR (2.24 Watts), Room Degrees (71.3 Degrees F), Audio CH1 (-31.7 dB), and Audio CH2 (-31.7 dB). Each meter has associated 'Lower Alarm' and 'Upper Alarm' indicators. On the left, there are settings for update intervals, event indicators, and external status inputs. On the right, there are sections for 'Relays' (with 'U' for unlatch, 'L' for latch, and 'M' for momentary) and 'Sequences' (1-16). A 'Log' section shows recent events.

Displays Current Access Level

Settings button opens the configuration menu in a new window.

Update interval defines how often your meters move. Event Indicators: Cust 1 & 2 light when user-defined events occur. Ext 1 & 2 show when either of the two external status inputs are closed.

Upper and lower trigger selector boxes. Unchecking these boxes will keep the unselected state from triggering an action.

Alarm trigger indicators show which triggers are active.

Sequence Status & Control: This box shows you all of the available sequences. The indicators at left of the labels change color to show active sequences. Controllers or administrators can manually run any sequence by pushing the "R" button. This is a very powerful control since it can perform multiple programmed steps.

Metering. Green background indicates normal operation. Red indicates an out-of-tolerance condition. Grey means that channel is not being monitored.


Relay controls: U is unlatch, L = Latch and the "M" button is momentary for duration of mouse-down. The "checkbox" has been added next to each relay function. When checked, this box disables changes to that relay, be it automated or by Web control. If a relay is latched and an automated script would have unlatched it, the relay will remain on. Uncheck the box for normal function. The indicators at the left of the labels show the relay's state. The indicators are polled at the hardware level to show you when a relay has closed, however, if the update interval is slower than the relay on time, the state may not be displayed.

The SiteSentry4's Web server display gives you the ability to monitor four DC metering channels, a stereo audio channel, a temperature sensor and to control six relays. Four of the relays are SPST while two are DPDT, suitable for either controlling external equipment or for switching audio. Relays can be latched or momentary.

The SiteSentry4 also has two status inputs that are monitored. Their status is shown in the upper left side of the screen as "Ext 1" and "Ext 2". When their inputs are connected to ground, the associated indicator turns from gray to green. External status inputs can also be used as events to initiate alarm actions.

SiteSentry4 Configuration:

Administrators and controllers can operate relays and view the meters. Readers can login to see the meters, but cannot control anything. Administrators can read meters, operate relays and perform configuration setup tasks, including editing labels by just clicking on them from the main page. Calibrating (scaling) readings, setting the meter scales and changing labels can be done without ever opening the configuration page.




Above: Quick-changing a Label (Admin Only)
Below: The main settings Form

In addition to quick changing the labels and calibrations, administrators can click on the “settings” button to open up the main configuration form in a new window.

The configuration form has 7 tabs. Each tab lets you configure a different aspect of the Site Sentry. Common tasks available include setting a static IP address, setup passwords for the various access levels, changing label names, defining under-voltage or overload levels for each channel and specifying the delay before an event is registered as an alarm and starts an action sequence.

Changes are highlighted in green or red until saved. Changes highlighted in red are illegal operations (for example, setting an upper alarm limit lower than the lower alarm limit for a channel) and won't be saved.



The action sequences are user-defined functions that the SiteSentry4 will perform whenever an event is triggered. These events are often called alarms, but they can also be simple responses to any particular input as defined by you.


The “alarms” are defined by two sets of parameters:

1. The triggering event
2. The step, or steps that you want to take when an event occurs.

Calibrating Meters:

Only administrators can calibrate the meters. This is best done when the output of your equipment is at its nominal operating voltage. Each input (except for onboard temperature) has a calibration control that is physically associated with the channel. The meter scale can be manually set or can be self-adjusting based upon where the pointer is and what value you assign to that metering input. Meters can be calibrated in just a few simple steps:

1. Log into the Web server for the SiteSentry4.
2. Apply a voltage sample to be monitored to the SiteSentry4's input.
3. Use that channel's calibration control to set the pointer to approximately the right spot on the dial. For most users this will be around $\frac{3}{4}$ of the way to the right side of the metering display
4. Set the meter's maximum scale so that the value you will be using will be within the meter's operational display range. For example, if you are currently reading 3.5, but will want the meter to read 5,000, click on the upper scale value and enter a number bigger than 5000, like 7000. The meter will rescale itself and your present value of 3.5 will be pegged to the bottom of the meter.
5. Click on the value currently displayed. This will allow you to directly enter the value that you want to record. When through, hit the enter key to set the value. The meter pointer will now move to the proper location on the meter face. The digital readout will also now reflect the correct reading. You can also adjust the scaler values on the telemetry configuration page.



6. Note that if you set the meter pointer to extend beyond the upper scale, the meter will read overload, even if there is still range in the A/D. If autorange was previously selected in the telemetry setup, the full scale value will self-adjust.

Note that calibrations are linear only. If your equipment outputs power or log scaled voltages, the readings will only be accurate at the calibrated voltage.

I/O Functions Quick Reference:

Meters 1-4 are the DC inputs. (differential, ground referenced).

Meter 5 is the onboard temperature sensor

Meters 6 and 7 are Channel 1 and Channel 2 (L & R) audio inputs. (Unbalanced, no gain controls on SS4-LE, Balanced, with gain set on the standard SS4).

Status inputs 1 & 2 are factory configured to turn on when the individual inputs are tied to "comm" or ground. These can be reconfigured for other types of drive circuits.

Relays 1 and 2 are DPDT.

Relays 3 through 6 are SPST.

The Telemetry Setup Tab of the SiteSentry

The screenshot shows the Telemetry Setup interface with several callout boxes:

- User Defined Channel Names:** Points to the 'Label' column in the channel table.
- User-set Unit Labels:** Points to the 'Unit' column in the channel table.
- Relay Labels:** Points to the 'Label' column in the relay table.
- Status input & front panel LED labels:** Points to the 'Label' column in the status input table.
- Color Selections:** Points to the 'ON color' and 'OFF color' dropdowns for relays and status inputs.
- Meter min & max scale values:** Points to the 'Minimum' and 'Maximum' columns in the channel table.
- Meter scalar and scalar type:** Points to the 'Scalar' and 'Scalar Type' columns in the channel table.

Channel	Label	Unit	Minimum	Maximum	Scalar	Scalar Type	Warn zone
Channel 1	Final Vvts	Vvts	0	100	30	Scale (%)	Green
Channel 2	Final Ahrs	Ahrs	0	55	10	Scale (%)	Green
Channel 3	Output Power	Watts	0	50	10	Scale (%)	Green
Channel 4	Reflected PWR	Watts	0	50	10	Scale (%)	Green
Channel 5	Room Degrees	Degrees	0	100	1	Scale (%)	Green
Channel 6	Audio Ch1	dB	-25	10	1	Scale (%)	Green
Channel 7	Audio Ch2	dB	-25	10	1	Scale (%)	Green

Relay	Label	ON color	OFF color
Relay 1	Audio Switch	Green	Black
Relay 2	Low Power	Green	Black
Relay 3	High Power	Green	Black
Relay 4	Raise/Lower	Green	Black
Relay 5	Override Reset	Green	Black
Relay 6	Reset ST...	Green	Black

Input	Label	ON color	OFF color
input 1	TS1	Green	Black
input 2	TS2	Green	Black

Temperature Sensor Reading: Fahrenheit

Enable Auto-Range for CH1-CH4:

Enable Auto-Range for temperature sensor:

Display warning zones on all channels:

Momentary relay action: Toggle

Relay momentary delay (ms): 300

The bottom fields are misc telemetry options:

You can change the temperature reading from F to C.

You can select auto-scale for the meters. When enabled, the meter max value will set itself as a function of where the meter pointer is (as a percentage of full scale) and what the value of the readings is.

Warning zones puts a splash of yellow on the meter face to indicate when the reading is close to a trigger point, but warning zones have no effect on the actual function of the device.

The momentary action selects how the relay will respond if it is in latch mode. If set to toggle, a latched relay will unlatch momentarily, then re-latch. If set to Latch-> Unlatch, the relay will unlatch, then momentarily latch on for the duration specified in the delay box. The delay box specifies the maximum closure for any momentary action.

Setting static IP addresses and resetting the SiteSentry2:

When you set a static IP address, your software and Web browser should automatically connect to the new IP address. You have 60 seconds to log in or else the unit will revert back to its previous IP address. **To force the change, unplug the power during the 60 second window.** The new address will be kept at power-up. If you set a static IP address that is not on your normal network mask, you could loose contact with the SiteSentry2. For example, if your network is configured to work in the range of 192.168.1.xxx and you inadvertently set your unit's static IP address to 192.168.0.xxx, then, on most networks, you will not be able to log into your SiteSentry2. Previously, there were only two solutions. One was to make a crossover cable and setup a computer to connect directly to the SiteSentry2 using the new network settings, but this only works if you didn't make a typo and therefore know the IP address of the unit. It's also a lot of work. The second solution was to reset your SiteSentry2 to factory defaults. This is easily done by shorting the internal pins marked "Reset" and toggling the power while maintaining the short. When the unit re-powers, it's back to defaults including obtaining a dynamic IP. We have added a step to this. Now when you reset your SiteSentry2, it will require two reset attempts if you have a static IP set. The first reset clears only the static IP flag and allows the unit to pick up a dynamic address. The second reset clears everything else.

Setting Alarm Points:

The SiteSentry4 uses a simple but flexible system for handling alarms. It can perform actions when conditions exceed upper or lower limits and it can perform actions when conditions return to normal, so it is possible to program a simple corrective action for one event and then to program another action to reverse the process when things return to normal. It has sixteen (16) event triggers (alarms) that can be programmed. Each trigger can respond to one of 16 possible conditions (upper alarms, lower alarms or status input changes). In order to activate a trigger, it is necessary to program the conditions that will cause the SiteSentry to trigger an event. Typically, these are lower or upper metering alarms, or status inputs. Lower and upper alarms are directly entered as a value (as opposed to a percentage of full meter scale as in earlier versions of the Sentry products). For instance, if you select an upper alarm of 900, the alarm will trigger whenever the scaled reading exceeds 900, but the trigger value must be on the meter's visible range. If the meter is from 0 to 5000 and a lower alarm is set to 1000, that will occur at 20% on the meter. At the point that the meter's value is reduced below the alarm threshold, the meter background will change to red or whatever color you have defined as the alarm color.

Telemetry condition out of normal range. (comparison made in Alarm Setup Tab).

Trigger Event (Set in the "Alarms" area)

Associated Sequence Runs

The Alarm setup box can be considered two forms in one.

The top half of the form is where you set the parameters that can trigger an event. It's also where you define the colors that will show up on your meter faces.

If you don't want alarms to show, just make them the same color as the meter's normal range. To disable an alarm, don't set a corresponding action. If you don't want to even see the tick marks for the alarm on the meter, just make the value of the alarm higher than the upper scale or lower than the lowest visible scale.

When setting lower alarm values, it's best to use some number other than zero because minor fluctuations of input signals can cause the meters to read greater than zero, especially if a large multiplier has been used in the telemetry scalar setting.

Label	Value	ON delay	OFF delay	Critical zone	Warning zone
Final Volts Lower Alarm	50.0	45	5	Red	Yellow
Final Amps Lower Alarm	30.0	45	5	Red	Red
Output Power Lower Alarm	3000.0	45	5	Red	Yellow
Reflected PWR Lower Alarm	0.0	45	5	Green	Green
Room Degrees Lower Alarm	32.0	45	5	Red	Cyan
Audio CH1 Lower Alarm	-40.0	45	5	Red	Violet
Audio Ch2 Lower Alarm	-40.0	45	5	Red	Silver

Label	Value	ON delay	OFF delay	Critical zone	Warning zone
Final Volts Upper Alarm	90.0	45	5	Red	Yellow
Final Amps Upper Alarm	45.0	45	5	Red	Yellow
Output Power Upper Alarm	4500.0	45	5	Red	Green
Reflected PWR Upper Alarm	35.0	45	5	Red	Yellow
Room Degrees Upper Alarm	120.0	45	5	Red	Yellow
Audio CH1 Upper Alarm	6.0	45	5	Red	Yellow
Audio Ch2 Upper Alarm	6.0	45	5	Red	Yellow

Input	ON delay	OFF delay
Input 1	1	1
Input 2	1	1

The bottom half of the form is where you set the event that will trigger a user-defined sequence. There are 81 possible triggering events (in the non streaming version) that can control one of 16 available sequences. The actual sequences are defined on the Sequences tab.

Label	Event	Sequence
Alarm #1	Disabled	Backup Aud ON
Alarm #2	Upper Alarm OFF (CH2)	Backup Aud OFF
Alarm #3	Upper Alarm OFF (CH3)	Sequence 3
Alarm #4	Upper Alarm OFF (CH4)	Sequence 4
Alarm #5	Upper Alarm OFF (CH5)	Sequence 5
Alarm #6	Upper Alarm OFF (CH6)	Sequence 6
Alarm #7	Upper Alarm OFF (CH7)	Sequence 7
Alarm #8	Upper Alarm OFF AND Upper Alarm ON (CH1 AND CH2)	Sequence 8
Alarm #9	Upper Alarm OFF OR Upper Alarm OFF (CH1 OR CH2)	Sequence 9
Alarm #10	Upper Alarm OFF AND Upper Alarm ON (CH1 NOT CH2)	Sequence 10
Alarm #11	Upper Alarm OFF AND Upper Alarm ON (CH2 NOT CH1)	Sequence 11
Alarm #12	Upper Alarm OFF AND Upper Alarm OFF (CH3 AND CH4)	Sequence 12
Alarm #13	Upper Alarm OFF OR Upper Alarm OFF (CH3 OR CH4)	Sequence 13
Alarm #14	Upper Alarm OFF AND Upper Alarm ON (CH4 NOT CH3)	Sequence 14
Alarm #15	Upper Alarm OFF AND Upper Alarm OFF (CH6 AND CH7)	Sequence 15
Alarm #16	Upper Alarm OFF OR Upper Alarm OFF (CH6 OR CH7)	Sequence 16

Event Triggers:

There are 81, non-streamng, events that can trigger actions.

Disabled	▼
Disabled	▲
Lower Alarm ON (CH1)	
Lower Alarm ON (CH2)	
Lower Alarm ON (CH3)	
Lower Alarm ON (CH4)	
Lower Alarm ON (CH5)	
Lower Alarm ON (CH6)	
Lower Alarm ON (CH7)	
Lower Alarm ON AND Lower Alarm ON (CH1 AND CH2)	
Lower Alarm ON OR Lower Alarm ON (CH1 OR CH2)	
Lower Alarm ON AND Lower Alarm OFF (CH1 NOT CH2)	
Lower Alarm ON AND Lower Alarm OFF (CH2 NOT CH1)	
Lower Alarm ON AND Lower Alarm ON (CH3 AND CH4)	
Lower Alarm ON OR Lower Alarm ON (CH3 OR CH4)	
Lower Alarm ON AND Lower Alarm OFF (CH3 NOT CH4)	
Lower Alarm ON AND Lower Alarm OFF (CH4 NOT CH3)	
Lower Alarm ON AND Lower Alarm ON (CH6 AND CH7)	
Lower Alarm ON OR Lower Alarm ON (CH6 OR CH7)	
Lower Alarm ON AND Lower Alarm OFF (CH6 NOT CH7)	
Lower Alarm ON AND Lower Alarm OFF (CH7 NOT CH6)	
Lower Alarm OFF (CH1)	
Lower Alarm OFF (CH2)	
Lower Alarm OFF (CH3)	
Lower Alarm OFF (CH4)	
Lower Alarm OFF (CH5)	
Lower Alarm OFF (CH6)	
Lower Alarm OFF (CH7)	
Lower Alarm OFF AND Lower Alarm OFF (CH1 AND CH2)	
Lower Alarm OFF OR Lower Alarm OFF (CH1 OR CH2)	
Lower Alarm OFF AND Lower Alarm ON (CH1 NOT CH2)	
Lower Alarm OFF AND Lower Alarm ON (CH2 NOT CH1)	
Lower Alarm OFF AND Lower Alarm OFF (CH3 AND CH4)	
Lower Alarm OFF OR Lower Alarm OFF (CH3 OR CH4)	
Lower Alarm OFF AND Lower Alarm ON (CH3 NOT CH4)	
Lower Alarm OFF AND Lower Alarm ON (CH4 NOT CH3)	
Lower Alarm OFF AND Lower Alarm OFF (CH6 AND CH7)	
Lower Alarm OFF OR Lower Alarm OFF (CH6 OR CH7)	
Lower Alarm OFF AND Lower Alarm ON (CH6 NOT CH7)	
Lower Alarm OFF AND Lower Alarm ON (CH7 NOT CH6)	
Upper Alarm ON (CH1)	
Upper Alarm ON (CH2)	
Upper Alarm ON (CH3)	
Upper Alarm ON (CH4)	
Upper Alarm ON (CH5)	
Upper Alarm ON (CH6)	
Upper Alarm ON (CH7)	
Upper Alarm ON AND Upper Alarm ON (CH1 AND CH2)	
Upper Alarm ON OR Upper Alarm ON (CH1 OR CH2)	
Upper Alarm ON AND Upper Alarm OFF (CH1 NOT CH2)	
Upper Alarm ON AND Upper Alarm OFF (CH2 NOT CH1)	
Upper Alarm ON AND Upper Alarm ON (CH3 AND CH4)	
Upper Alarm ON OR Upper Alarm ON (CH3 OR CH4)	
Upper Alarm ON AND Upper Alarm OFF (CH3 NOT CH4)	
Upper Alarm ON AND Upper Alarm OFF (CH4 NOT CH3)	
Upper Alarm ON AND Upper Alarm ON (CH6 AND CH7)	
Upper Alarm ON OR Upper Alarm ON (CH6 OR CH7)	
Upper Alarm ON AND Upper Alarm OFF (CH6 NOT CH7)	
Upper Alarm ON AND Upper Alarm OFF (CH7 NOT CH6)	
Upper Alarm OFF (CH1)	
Upper Alarm OFF (CH2)	
Upper Alarm OFF (CH3)	
Upper Alarm OFF (CH4)	
Upper Alarm OFF (CH5)	
Upper Alarm OFF (CH6)	
Upper Alarm OFF (CH7)	
Upper Alarm OFF AND Upper Alarm OFF (CH1 AND CH2)	
Upper Alarm OFF OR Upper Alarm OFF (CH1 OR CH2)	
Upper Alarm OFF AND Upper Alarm ON (CH1 NOT CH2)	
Upper Alarm OFF AND Upper Alarm ON (CH2 NOT CH1)	
Upper Alarm OFF AND Upper Alarm OFF (CH3 AND CH4)	
Upper Alarm OFF OR Upper Alarm OFF (CH3 OR CH4)	
Upper Alarm OFF AND Upper Alarm ON (CH3 NOT CH4)	
Upper Alarm OFF AND Upper Alarm ON (CH4 NOT CH3)	
Upper Alarm OFF AND Upper Alarm OFF (CH6 AND CH7)	
Upper Alarm OFF OR Upper Alarm OFF (CH6 OR CH7)	
Upper Alarm OFF AND Upper Alarm ON (CH6 NOT CH7)	
Upper Alarm OFF AND Upper Alarm ON (CH7 NOT CH6)	
Input 1 ON (IN1)	
Input 2 ON (IN2)	▼

The first thirty-eight are permutations of low-meter conditions. You can react to low conditions on one or two channels, or you can react to the return of normal readings on those same channels. For multiple triggers, the channels may be grouped in pairs, Ch1 & CH2, Ch3/4 and Ch6/7 (Audio).

Similar to low meter detection, overload detection indicates when too much voltage is present on a channel.

The four External "ON" events occur whenever one or both of the external status inputs are triggered, while the four External "OFF" events happen whenever the external status inputs are untriggered.

Each of these trigger events can be used to perform a different action. For instance, one alarm event (and action) might be if a low meter detection on channel 1 causes relay #1 to latch "ON". A second event might then be used to unlatch relay #1 when low meter "OFF" (back to normal) condition is detected on channel one. By using two alarm events, you can create an automatic switchover system that will operate whenever a situation occurs and will automatically reverse itself whenever condition returns to normal.

Each channel's upper and lower triggers are governed by their own set of timers, so you can choose how quickly the SiteSentry4 will respond to a particular condition. For instance, the Audio Silence detection might be set to occur after 30 seconds of silence on both channels (6 & 7), but you might want to know that the audio has returned after only 5 seconds, so that you can restore main programming. In that case, you would probably set an action sequence to occur on Silence OFF on either channel 6 or 7 and set both off delays to 5 seconds. Setting a timer to zero is an instant response.

Each "alarm" trigger can operate any one of the 16 available action Sequences

Sequences:

Telemetry	Alarm Setup	Notifications	Connectivity	Misc	Streaming	Sequences
Sequence Label	Action #1	Pause	Action #2	Pause	Action #3	Pause
Sequence 1	Backup Aud ON Latch: Relay Relay 1	0	Turn ON FP LED Front Panel LED 2	0	Dispatch Email Receiver(s) Index 2	0
Sequence 2	Backup Aud OFF Unlatch: Relay Relay 1	0	Turn OFF FP LED Front Panel LED 2	0	Dispatch Email Receiver(s) Index 2	0
Sequence 3	Sequence 3	0	No Action	0	No Action	0
Sequence 4	Sequence 4	0	No Action	0	No Action	0
Sequence 5	Sequence 5	0	No Action	0	No Action	0
Sequence 6	Sequence 6	0	No Action	0	No Action	0
Sequence 7	Sequence 7	0	No Action	0	No Action	0
Sequence 8	Sequence 8	0	No Action	0	No Action	0
Sequence 9	Sequence 9	0	No Action	0	No Action	0
Sequence 10	Sequence 10	0	No Action	0	No Action	0
Sequence 11	Sequence 11	0	No Action	0	No Action	0
Sequence 12	Sequence 12	0	No Action	0	No Action	0
Sequence 13	Sequence 13	0	No Action	0	No Action	0
Sequence 14	Sequence 14	0	No Action	0	No Action	0
Sequence 15	Sequence 15	0	No Action	0	No Action	0
Sequence 16	Sequence 16	0	No Action	0	No Action	0

Save

Any trigger event can perform any of the 16 action sequences on the “sequences” list. There are nine basic (non-streaming) actions available and a sequence can run up to seven (formerly three) actions. Available actions include operating relays, either momentarily or latching, sending e-mails, turning on LEDs on the box, and muting or unmuting alarms (triggers).

When a latching action is performed, often a matching “unlatch” or “release” event is used to undo the action when the triggering event is over. For example, if audio is lost (silence ON), you might latch relays 1 and 2 “on” to act as a stereo, balanced audio switcher. When audio is restored (Silence OFF), you might unlatch relays 1 and 2 to switch back to regular programming.

In addition to operating relays, the custom LEDs can be operated. The Custom LEDs are represented graphically on the Web server as gray (off) or green (on) lights. There are also two real LEDs on the front panel of the SiteSentry4 that can be operated by the same actions.

Each sequence can have up to three steps. There are programmable pauses available between steps as well. Using these, it is possible, for example, to have one event, close a relay, turn on one of the LEDs and then pause for a few seconds, then close, or open, another relay or send an e-mail.

Whenever actions are occurring, the SiteSentry4 will not respond to outside commands or to other events until the action has completed. If a pause is set to 60 seconds, then the SiteSentry4 will not be responsive to outside control, nor will it update its meters, until that time, plus whatever amount of time to run the action steps has passed.

Logging:

The SiteSentry4 can keep a log and can also e-mail it to you. Logging can be as simple or complex as desired. The log is a FIFO (First In, First Out) circular buffer. When the buffer is full, new entries push the oldest entries off the stack. The log can hold about 50 entries. Log entries can be by time or by action sequence, such as might occur in an alarm condition.

The output format of the logger is defined in the logging setup. The default format produces an easily read log but the format can be altered to read in any way desired by using the items from the drop down list. The log is divided into two parts, the header and the body. The header is printed at the beginning of the log and periodically throughout the log as defined by you in the first setup field. Any text that does not match a keyword is printed exactly as typed. For example, if you want meter one to print the value followed by the label "Amps", you would simply add the label after the meter value. If meter 1 is the Amp meter, then it would be entered as %mv1Amps instead of just %mv1.

The screenshot shows the 'Logging' configuration page for SiteSentry4 v1.0. The page includes several settings and template editors:

- Print header every N entries; 0 disables header print:** Set to 20. Callout: "Defines how often to print the header within the log file."
- Last N log entries to email:** Set to 10. Callout: "Defines how many log entries to include with an e-mail"
- Log interval (in minutes); 0 disables timed logging:** Set to 180. Callout: "Defines how often to log a set of readings when time-based."
- Display log in reverse order (newest entry last):** Checked.
- Run sequence X every N entries; 0 disables this feature:** Set to Sequence 1 every 0 entries. Callout: "Lets you run a sequence based on how many log entries have happened. Be careful not to create a loop by having a logging command in the sequence that you use.."
- Log header template:** A text area with a table header: | Date/Time | Channels | Inputs | Relays |. Below it is an 'Insert' dropdown set to 'Year (%dy)' and a 'Save Log Header Template' button.
- Log entry template:** A text area containing the format string: | %dy-%dm-%dd %th:%tm:%ts | %mv1 %mv2 %mv3 %mv4 %mv5 %mv6 %mv7 | %sv1%sv2 | %rv1%rv2. Below it is an 'Insert' dropdown set to 'Year (%dy)' and a 'Save Log Entry Template' button.

At the bottom of the page, there is a callout box: "The bottom half of the form is where you define the format of the log".

CircuitWerkes Site Sentry 4 Web Interface v1.0, Web Server Firmware v1.0
©Copyright 2012, CircuitWerkes, Inc.
Best viewed on IE7+, Chrome, Firefox 4+ in 1024x768+ resolution

An example of a modified logging setup.:

The default header looks like this:

```
| Date/Time | Channels | Inputs | Relays |
```

In order to get the output below, the following header was created:

```
| Date/Time | Channels | Inputs | Relays |
| 1 2 3 4 Temp Aud1 Aud2 | 1 2 | 123456 |
```

The result is below....

```

| Date/Time | Channels | Inputs | Relays |
| 1 2 3 4 Temp Aud1 Aud2 | 1 2 | 123456 |
T | 12-09-13 14:12:57 | 0.000 0.000 0.000 4.940 77.000 -4.696 -7.933 | 00 | 000000 |
T | 12-09-13 14:13:57 | 0.000 0.000 0.000 4.940 77.000 -10.912 -10.525 | 00 | 000000 |
T | 12-09-13 14:14:57 | 0.000 0.000 0.000 4.940 77.000 -12.655 0.081 | 00 | 000000 |
T | 12-09-13 14:15:57 | 0.000 0.000 0.000 4.987 77.000 -14.837 -6.396 | 00 | 000000 |
T | 12-09-13 14:16:57 | 0.000 0.000 0.000 4.940 77.000 -2.491 -4.891 | 00 | 000000 |
T | 12-09-13 14:17:57 | 0.000 0.000 0.000 4.940 77.000 -5.091 -3.112 | 00 | 000000 |
T | 12-09-13 14:18:57 | 0.000 0.000 0.000 4.940 77.000 -9.461 -12.655 | 00 | 000000 |
T | 12-09-13 14:19:57 | 0.000 0.000 0.000 4.940 77.000 -6.396 -7.933 | 00 | 000000 |
T | 12-09-13 14:20:57 | 0.000 0.000 0.000 4.940 77.000 -4.135 -4.891 | 00 | 000000 |
T | 12-09-13 14:21:57 | 0.000 0.000 0.000 4.940 77.000 -4.891 -2.343 | 00 | 000000 |
T | 12-09-13 14:22:57 | 0.000 0.000 0.000 4.940 77.000 -12.655 -12.185 | 00 | 000000 |
T | 12-09-13 14:23:57 | 0.000 0.000 0.000 4.940 77.000 -6.396 -5.295 | 00 | 000000 |
T | 12-09-13 14:24:57 | 0.000 0.000 0.000 4.940 77.000 -5.295 -22.197 | 00 | 000000 |
T | 12-09-13 14:25:57 | 0.000 0.000 0.000 4.940 77.000 -8.817 -10.525 | 00 | 000000 |
T | 12-09-13 14:26:57 | 0.000 0.000 0.000 4.940 77.000 -6.396 -8.512 | 00 | 000000 |
T | 12-09-13 14:27:57 | 0.000 0.000 0.000 4.940 77.000 -7.657 -9.801 | 00 | 000000 |
T | 12-09-13 14:28:57 | 0.000 0.000 0.000 4.940 77.000 -15.481 -14.837 | 00 | 000000 |
T | 12-09-13 14:29:57 | 0.000 0.000 0.000 4.940 75.755 -3.781 -12.185 | 00 | 000000 |
T | 12-09-13 14:30:57 | 0.000 0.000 0.000 4.987 75.755 -8.817 -4.696 | 00 | 000000 |
T | 12-09-13 14:31:57 | 0.000 0.000 0.000 4.940 75.755 -6.164 -5.719 | 00 | 000000 |
| Date/Time | Channels | Inputs | Relays |
| 1 2 3 4 Temp Aud1 Aud2 | 1 2 | 123456 |
T | 12-09-13 14:32:57 | 0.000 0.000 0.000 4.940 77.000 -19.698 -25.719 | 00 | 000000 |
T | 12-09-13 14:33:57 | 0.000 0.000 0.000 4.940 75.755 -13.151 -5.719 | 00 | 000000 |
T | 12-09-13 14:34:57 | 0.000 0.000 0.000 4.987 75.755 -0.858 -4.891 | 00 | 000000 |

```

The first character is either a T for time triggered or a sequence number (like S13) to indicate what caused the log reading to be taken.

E-mail notifications Setup

My Transmitter - Site Sentry 4 v1.0 Settings - Opera

Open Save Print Find Home Tile Cascade Voice

sicon8.dyndns.org

Telemetry Alarm Setup **Notifications** Connectivity Misc Streaming Sequences

SMTP Server settings:

Server: smtp.my-lsp.net

Port: 25

Username: my_user_name

Password:

From: Type a valid reply address here

Subject: Mail from My Transmitter

Save SMTP Settings

Last server response code: 32768

Recipient list (max: 80 characters per index location):

Recipient(s) IDX 1:	P.L as many addresses as desired in each index separated by commas	Test Email
Recipient(s) IDX 2:		Test Email
Recipient(s) IDX 3:		Test Email
Recipient(s) IDX 4:		Test Email
Recipient(s) IDX 5:		Test Email

Save Recipient List

E-mail notifications can be sent to you for alarm purposes as part of your sequences. In order to send mail, you must use a mail server that does not require SSH secure access. Most unsecured mail servers will use port 25. If your server requires port 995 or 465, it's probably not going to work.

For mail servers that require a user name and password, there are fields provided to enter the required information.

The "From" field should normally contain a valid reply to address. Some mail servers will not deliver mail unless there is a valid reply to address.

The "Subject" field is the title that will be prepended to each e-mail's subject line.

The bottom half of the form has five fields for entering e-mail addresses. **Each field can contain more than one address, separated by a comma for each.**

SMS texts are actually just e-mails sent to the target mobile number at the carrier's SMS domain name. For example, 987-654-3210@txt.att.net (no dashes would be entered in the phone number, of course).

Connectivity (Network settings):

The SiteSentry allows you to change almost everything about the network configuration.

The HTTP port is typically 80, but you can change it to anything that you want.

The MAC address is unique to each unit and is not user changeable, however, it is possible for the factory to alter your unit's MAC address in the field using a special utility. We must have direct access to your unit to change the MAC address.

Current Remote IP	74.179.113.182
Current Local IP	192.168.0.154
HTTP Port	80
MAC Address	00:04:A3:00:00:01
NETBIOS Hostname	SITESENTRY4
Static IP (0.0.0.0 = not used/DHCP enabled)	0.0.0.0
Subnet Mask	255.255.254.0
Default gateway	192.168.0.1
Primary DNS server	192.168.0.1
Secondary DNS server	0.0.0.0

The Netbios Name is optional and allows you to find computers or devices by name instead of knowing their IP address. When you call a Netbios name, a request is sent across the network for a response from any device with the matching name. If that device has a Webserver, it can be loaded into your browser directly without calling the IP address, much like a domain name works over the Internet.

When calling a device by its NetBios name, it should be entered complete with the http:// preceding the device name. For example entering <http://sitesentry4/> into the address bar will work whereas just sitesentry4/ won't. Also, Android does not support NetBios calls, so you have to know the IP address of the product when browsing in using Android devices.

The SiteSentry is normally configured for DHCP by setting the four address octets to 0.0.0.0. If you want to enter a static IP address, you can direct enter it in the Static IP field as ###.###.###.###.

When set to DHCP, the SiteSentry will detect the default gateway and enter its address in the "Default Gateway" field and also in the "Primary DNS Server" field. When a static IP is set, you can alter the gateway and DNS fields manually.

Differentiating multiple devices on a common network:

The SiteSentry4 has a fixed, unique MAC address but allows you to change the IP address and Netbios name of the device. These can be important when multiple CircuitWerkes Webserver based products are used at a common location. In that case, you will want to assign a unique Netbios name to each device so that each device can be found by a unique name. If using static IP addresses, you will need to set a unique one for each device.

Dynamic DNS (beta):

Dynamic DNS allows you to operate devices requiring a static address on networks that have only dynamic IP addresses. You make up a name for your location and register it with a DDNS service. Whenever your IP address changes, the device detects the change and notifies the host DNS service. The host service then modifies the address that the name points to. So when you try to login using the name, it always points to the right address. Currently the SiteSentry supports dyndns.org, no-ip.com and dnsomatic.com. All of these services offer free and paid services. After setting up an account, enter your credentials into the fields of the DNS settings page and save them. DDNS has been tested, but is considered a beta feature.

DDNS Service:	members.dyndns.org
Username:	members.dyndns.org
Password:	dynupdate.no-ip.com
Host:	updates.dnsomatic.com
Status:	undefined

DDNS is not available on audio streaming units due to programming space limitations.

Passwords and system utilities:

In the MISC tab you can change access codes for the three classes of users. Administrators can configure and control the SiteSentry. Controllers cannot configure the device, but can operate its controls. Readers can only see the main page and cannot operate any relays.

Timed sequences let you perform actions based on elapsed time. Using these you can perform a task every hour, every 24 hours or every 168 hours (week).

The time setup box lets you set the current time and also selects how often to automatically sync the SiteSentry clock to an NTP server. The NTP server list is embedded in the stack and is not currently user adjustable. Time is currently only used to time-stamp log entries, but may be used for other processes in the future. Setting NTP update to zero disables updating.

The resets/reboot section lets you restart your SiteSentry or load default values. The connectivity button changes the MAC address, Netbios name, IP port number and IP address back to defaults, but leaves the main configuration data intact. The bottom button overwrites everything with default data. This is a requirement when upgrading the firmware.

The import/Export functions are VERY important. Here is where you can save your configuration data to a local file. You can also load saved data into a virgin SiteSentry without having to program everything from scratch. When you click the "Export" button, you will be presented with a text box containing a lot of information. Select the entire contents of the box (CTRL-A in Windows). Copy the entire contents to the clipboard (CTRL-C). Then open up a text writer like notepad and paste everything into it (CTRL-V). Save the new file.

To import saved data, open the text file that you previously saved and copy everything to the clipboard (CTRL-A, then CTRL-C). Then click the "Import" button and paste the contents of the clipboard to it and click the "Import" button on this form. When done importing, click the "Save" button at the bottom of the main form, or click any of the save buttons on any of the other tabs. Note that network settings are not automatically saved because they would cause the unit to potentially change IP addresses in the middle of the process and you might not find it if you don't know what IP address and range it is using. Therefore, you have to make those changes individually.

The screenshot shows the 'Misc' tab of the SiteSentry web interface. It contains several sections:

- Passwords:** Three rows for 'Admin Password:', 'Controller Password:', and 'Reader Password:', each with a text input field and a 'Submit' button.
- Timed sequences:** Three rows, each with a label 'Timed sequence run; 0 disables timed run', a dropdown for 'Sequence #1', a frequency selector (e.g., 'every'), and a time input (e.g., '0 hour(s)').
- Time Setup:** A section for 'Current date/time stamp (MM-DD-YY HH:MM:SS)' showing '09-13-12 16:26:13'. It includes a 'Sync with PC' button, a manual date/time input field (MM-DD-YY HH:MM:SS), and 'NTP Update interval (in minutes)' (set to 30) and 'GMT Offset (in minutes)' (set to -300).
- System Utilities:** A 'Reboot the unit' section with a 'Confirm Reboot' button. Below it are 'Load factory defaults' buttons: 'Load Factory Defaults (Only Connectivity)' and 'Load Factory Defaults (Everything)'. At the bottom is an 'Import/Export settings' section with 'Import' and 'Export' buttons.

CircuitWerkes Site Sentry Web Interface v1.0, Web Server Firmware v1.0
©Copyright 2012, CircuitWerkes, Inc.

Best viewed on IE7+, Chrome, Firefox 6+ in 1024x768+ resolution

Note that the configuration page lets you export and import settings from your browser. On some computers, the import/export function may only work properly with Internet Explorer.


Optional Streaming

The SiteSentry series offers an optional hardware upgrade that lets you receive Shoutcast compatible mp3 or Ogg-Vorbis streams. Receiving audio can be used as a backup audio source for routing the air. The optional streaming module also lets you encode (transmit) Ogg-Vorbis streams in stereo or mono at various bitrates. Encoded streams are useful as confidence audio, letting you verify that your audio is reaching the transmitter site properly. The Ogg-Vorbis streams are of very high quality, rivaling AAC at medium & high bitrates. The encoded streams can be received on many media players including VLC, Foobar 2000, and WinAmp (with the Ogg plugin). Transmit audio, although high quality, is only intended for confidence monitoring, not as a point-to-point streaming source for critical applications. Due to a small transmit buffer size only one client can be connected at a time and dropouts can occur periodically in the encoded stream.


The streaming setup controls will only be enabled if the streaming hardware is present. When no streaming hardware is present, the streaming tab will only have a notice that streaming is not available on this version. The streaming module information will also not appear on the main metering page.

Transmit Audio Mode:


In the transmit mode, the main metering page shows you the mode (Transmit), the status (ready or occupied) and the IP address of the remote client, if any. There is a button labeled “kick”. If there is a remote client connected to your stream that you don’t want, you can use the “kick” button to disconnect them. The “Socket Ready” text tells you no one is currently connected. When a remote client is connected, their IP address is displayed and the simulated LED will be green.



Transmit Audio Setup



The transmit mode has two main settings groups that you can change. First is the quality mode. You can choose from CD quality stereo, through several low bitrate medium quality stereo or mono settings. Very low (voice only) quality settings are available for networks with extremely limited bandwidth. The second main settings group are the auto-gain settings. The encoder uses an optional DSP based AGC & peak limiter to maintain optimum encode amplitude. The AGC/limiter is optional and can be disabled by un-checking the “AutoGain” box. The AGC has a setting that limits the maximum gain to avoid pumping and noise pickup during low passages. In order to avoid pumping and sucking up of noise, we suggest setting the AGC limit to four or less and use the audio drive controls to feed a high level to the encoder.




Receive Audio Mode:

In the receive mode, the SiteSentry can decode Ogg-Vorbis or mp3 shoutcast compatible streams. When in the receive mode, the Audio module on the main page will display the connection information along with buttons to connect or disconnect. If enabled in setup, sliders for adjusting the output gain will be present as well.



Receive Audio Setup

When set to receive mode, you can set up to five receive stations. Each of these stations consists of the IP address and port number of the streaming audio. The five streaming sources form a "hunt" group, meaning that if the stream from one fails, the decoder can be set to move down the list to the next. Each streaming source can be individually enabled. If not enabled, that stream will not be included in the hunt group. Each index of the hunt group can be named for easy recognition. Below the hunt group are the five indexes as radio buttons. Here you can select which will be active (the main stream).



Persistent decoder connect and retry attempts: When persistent decoding is enabled, the SiteSentry will try each index the user defined number of retries before moving on to the next. When the last index is reached, the loop will start over until a connection is achieved.


Treble and Bass controls: These DSP based controls are built-in to the decoder hardware. You can adjust the knee frequencies and the amount of boost for each. These controls only work at lower audio output levels (below -15dB for full effect). Because operating the decoder output at a lower level can result in increased noise (due to the low level needing to be amplified more downstream), you should decide if the advantages of using the tone controls is worth any noise penalty that you might face. Note: The treble controls are not enabled on this version, however bass is.

You can also set the delay before registering the loss of streaming as an alarm. The stream alarm resets whenever a stream is successfully started, even if it is not the primary.


The variable playback box is only used for some obscure Ogg-Vorbis streams and should not be used 99.99% of the time.

Receive Audio hardware:

SiteSentry4's with the streaming option also have an audio output daughter board installed that amplifies the received audio stream and gives you an active, balanced, output from the streaming engine.



Leave unused outputs floating. Do not ground them.



Firmware upgrades:

The SiteSentry can be field upgraded when new features are added or when bugs are corrected. A special password protected webpage is the gateway to upgrading. After upgrading, you must always reset your unit to factory defaults, so be sure that you have saved your configuration data before starting the upgrade process. Firmware is loaded in two parts: The operating system (steps 1-3) and the user interface software (steps 4-7).

To flash new firmware, first obtain the newest .DFF and .BIN files for your SiteSentry from our Website.

Step 1. You must download the CircuitWerkes firmware loader tool from our Website.

Step 2. Run the FW loader tool and select the DFF file that you downloaded for your SiteSentry.

Step 3. Set the IP address of your SiteSentry in the loader tool and upload the DFF file to your unit.

Step 4. Using a browser, log into ###.###.###.###/imageflash

If you're using a port other than 80, it would look like this: ###.###.###.###:PORT#/imageflash

Step 5. Login as Admin and use the administrator code that you have set. Default = 12345678.

Step 6. Click the choose button and browse to find the .BIN file that you will be uploading.

Step 7. Click "Upload" to send the new BIN to the SiteSentry.

Step 8. Reset your SiteSentry to factory defaults. If using the hardware reset, do it at least 2x. Each time you reset the unit, wait, with power applied, for 10 seconds before removing power for the next reset.

Step 9. Import/Upload your configuration data back to the unit and save the changes. Note that connectivity settings and passwords have to be done manually, one at a time.

Software:

The SiteSentry will have accompanying multi-site capable software, similar to the Silence Sentinel and the SiteSentry2 version 1.xx products. The software for the SiteSentry4, SiteSentry2 v2 and WAM-2 (audio monitor) is in active development, and eventually, will be capable of monitoring all three products from the same interface. The software is not necessary to use these products, however, it will provide a unified tool for multi-site monitoring and control. A beta release is expected within weeks. When the software is ready, it will be posted on our Website for free download.

Specifications

Dimensions	1.75" H x 8.5" W x 6" D 1RU rack-shelf-mountable
Weight	approx. 3 lbs.
Power	15Vdc supplied by included 117VAC @ 60 Hz wall adaptor
Relays	4 SPDT relays rated at 10va @ 15 VDC. 2 DPDT relays rated at 1 A @ 30 VDC, 0.3 A @ 125 VAC for 5 x 10 ⁵ cycles



CAUTION: While the SiteSentry's DPDT relays can handle 120 VAC, this practice is very dangerous and is strongly discouraged by CircuitWerkes. Switching of hazardous voltages should only be done in a manner that isolates the voltages from accidental contact with people. Don't ever switch lethal voltages directly with the SiteSentry! Ever.

Metering Inputs - 4 DC site inputs in 3.5mm depluggable screw terminals capable of accepting 0 to 10V with reference to ground. Negative voltages can be measured via the (-) metering inputs.

Audio Inputs - Balanced stereo input on the SiteSentry4 or unbalanced on the SS4-LE. Can detect silence or overload.

Temperature sensor - Displays ambient temperature at the back panel of the PCB. Configurable for F or C. Low and High temp alarms.

Status Inputs - 2 contact-closure inputs. Pull to ground to activate or supply your own voltage (jumper configured).

Ethernet - Internal Web server with DHCP or static IP capability. Browser must have Javascript.

Relay outputs

Six total relays on board. Two are DPDT with contacts rated at 1amp. The remainder are SPST with contacts rated at 10VA (100ma MAX NON-Inductive). All relays can be momentary or latching

Alarms

16 onboard alarms can respond to 81 possible conditions, each. Responses can consist of single or up to 3 actions, performed in sequence, with user defined pauses. A list of available actions lets the user define which actions can be taken for a given alarm.


Notifications

The onboard e-mailing function can send e-mails or SMS messages when alarm conditions are present. In future release of multisite software, you will be able to trigger notifications if any of the sites enter alarm. For secured mail servers, the software will have an option to use the default mailer program, such as Outlook Express, to send the notifications.

Logging

A simple log is kept and updated at a user defined interval (default 3hrs). The log can be downloaded via the Webserver. Each log entry is time and date stamped. Time and date are kept updated by an internal pool of NTP servers. If NTP is not available, the clock can be manually set and the clock will continue to operate without NTP.

SiteSentry4 With Audio I/O for Streaming



SiteSentry4
Copyright 2011-2012 CircuitWerkes, Inc.
All Rights Reserved

SiteSentry4 Schematic. Note the SiteSentry4-LE is similar but lacks the balanced audio input/output.

Warranty

CircuitWerkes, Inc. (Manufacturer) warrants that this product is free of defects in both materials and workmanship. Should any part of this equipment be defective, Manufacturer agrees, at its option, to:

- A. Repair or replace any defective part free of charge (except transportation charges) for a period of two years from the date of the original purchase, provided the owner returns the equipment to the Manufacturer at the address set forth below or stated at time of RMA issue from Manufacturer. No charge will be made for parts or labor during this period:
- B. Furnish replacement for any defective parts in the equipment for a period of two years from the date of original purchase. Replacement parts shall be furnished without charge, except labor and transportation.

This warranty excludes assembled products not manufactured by Manufacturer whether or not they are incorporated in a Manufacturer product or sold under a Manufacturer part or model number.

THIS WARRANTY IS VOID IF:

- A. The equipment has been damaged by negligence, accident, act-of-God or mishandling, or has not been operated in accordance with the procedures described in the operating and technical instructions; or,
- B. The equipment has been altered or repaired by other than Manufacturer or authorized service representative of Manufacturer; or,
- C. Adaptations or accessories other than those manufactured or provided by Manufacturer have been made or attached to the equipment which, in the determination of Manufacturer, shall have affected the performance, safety or reliability of the equipment; or,
- D. The equipment's original serial number (if applicable) has been modified or removed.

NO OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE, APPLIES TO THE EQUIPMENT, nor is any person or company authorized to assume any warranty for Manufacturer or any other liability in connection with the sale of Manufacturer's products.

Manufacturer does not assume any responsibility for consequential damages, expenses or loss of revenue or property, inconvenience or interruption in operation experienced by the customer due to malfunction in the purchased equipment. No warranty service performed on any product shall extend the applicable warranty period.

In case of unsatisfactory operation, the purchaser shall promptly notify Manufacturer at the address set forth below in writing, giving full particulars as to the defects or unsatisfactory operation. Upon receipt of such notice, manufacturer will give instructions respecting the shipment of the equipment, or such other matters as it elects to honor this warranty as above provided. This warranty does not cover damage to the equipment during shipping and Manufacturer assumes no responsibility for such damage. All shipping costs shall be paid by the customer.

Repair or Service Information

In the event of the need for service or repair, call CircuitWerkes at (352) 335-6555 for a Return Merchandise Authorization number (RMA). Then carefully package the unit along with a note of the problem and send it to the address below. Be sure to include your contact information (address - not PO Box - telephone numbers) and best time to call.

This warranty extends only to the original purchaser and is not assign-able or transferable.

CircuitWerkes • 2805 NW 6th Street • Gainesville, FL 32609
Voice 352.335.6555 • Fax 352.380.0230 • info@circuitwerkes.com • www.circuitwerkes.com